



## www.customcurtains.co.nz 0508 CURTAINS (0508 287 824)

## SIZE & MEASURE GUIDE ROMAN BLINDS


Our Roman Blinds are made to sit outside the window frame, rather than inside. Fitting blinds inside the frame obstructs much of the view through the window, and light will come through gaps around the edges of the blind.

The ideal size/position of an outside fit roman blind is 10cm above the window frame, coming down to 10cm below the windowsill, and covering 5cm either side of the window frame (to the left and the right). This extra tolerance is a guide only and a little bit more or less is OK. For example, you might have two windows of a similar size in the same room, but to give a uniform look, you could make the roman blinds both the same size.

Please take these allowances into account when giving us your measurements. We <u>do not</u> work from your window measurements alone, we need the finished size of the blind that you require.

We make our widths and drops in increments, so please choose the nearest size that fits your requirement.

		total width of blind (cm)																
		50	60	70	80	90	100	110	120	130	140	150	160	170	180	190	200	210
total length of blind (cm)	90			2	- 0		9	V .					118	100	9	Ÿ		
	120																	
	150			2	- 6		3	V .				7	- 8		3	ξ.	n/a	n/a
	180												- 1			n/a	n/a	n/a
	210			2	- 6		3	¥				- 2	- 8		n/a	n/a	n/a	n/a



## WIDTH:

This is the total width of your blind, including the 5cm extra allowance on each side (more or less allowance is OK).

The maximum width blind we can supply is 210cm.

## LENGTH/DROP:

The total length of the blind, including the 10cm allowance top and bottom (more or less allowance is OK).

Take your measurement down to where you want your blind to finish and then select the closest length available from the drop down list on the order screen.